## **Advertising Flag Ground Spike**



Ground spike is inserted into the ground.



If ground is hard, a hammer can be used. Hammer on the taller post. Do not hammer on the swivel peg.





Once ground spike is secure in the ground, place the flag onto the swivel peg (the shorter peg).



When properly installed, the flag will swivel and follow the direction of the wind. It is recommended to <u>not</u> display or fly the flag in adverse weather conditions including high wind.