


## Set Up Instructions

### Step 1

Prepare the stand. Remove from case.




### Step 2

Fill ballast tank with water.



### Step 3

Locate the receiving hole on the stand base and insert the pole.



### Step 4

Grasping the “top bar” from the center, pull banner up, out of the base.



### Step 5

Attach one clamp rail (top bar) to the top of the pole. Attach the second clamp rail (top bar) to the top of the pole.



### Step 6

Set up complete.



For videos demonstrating setting up a banner stand, visit: [amatterofgraphics.com](http://amatterofgraphics.com)

\*Hardware Warranty warrants product against defects in materials, workmanship and mechanical failure of internal retraction unit based on normal use. Graphic Warranty covers the print vibrancy and media performance. Neither warranty covers damage due to accidents, abuse, mishandling, or normal wear and tear. Any repair or replacement is at discretion of factory.