Set Up Instructions (XS24 & XS32)

Step 1

Remove the stand and pole arms from the carry case.



Step 2

While holding the stand against the floor, extend the front legs forward, away from you.



Step 3

Insert the two upper poles into the top of the center hub.

Note: the XS32 model has pole arms that come in 2-pieces (pole arm + extender).



Step 4

Hang the banner on the top hooks first and then stretch to meet the bottom hooks. (Bottom hooks are adjustable).



For videos demonstrating setting up a banner stand, visit: amatterofgraphics.com